

| | | | | | | |
|-----------|------|------|------|---|---|--|
| 726-73-01 | xxxx | xx** | xx-- | TrailerTow_Cfg: 00=No Relays 01=Relays | | Indicates if Trailer Tow Relays are installed or not |
| 726-69-02 | xxxx | **xx | xx-- | TBM_Available_Cfg: 00=Absent 01=Present | | Trailer Brake Control Module(TBM) |
| 726-69-02 | xxxx | xxxx | **-- | TRM_Available_Cfg: 00=Absent 01=Present | | Trailer Tow Module (TRM) |
| BCM | | | | Bulb_Quality_Cfg (BQC) • PSCM_Enable_Cfg (PSCMEC) • SYNC_Exists_Cfg (SYNCEC) • TBM_Cfg (TBMC) | | |
| 791-01-02 | xxxx | x*-- | | 0 = BQC NOT_CONSIDERED · PSCMEC DISABLE · SYNCEC ABSENT · TBMC NOT_PRESENT | 8 = BQC CONSIDERED · PSCMEC DISABLE · SYNCEC ABSENT · TBMC NOT_PRESENT | |
| TRM | | | | 1 = BQC NOT_CONSIDERED · PSCMEC DISABLE · SYNCEC ABSENT · TBMC PRESENT | 9 = BQC CONSIDERED · PSCMEC DISABLE · SYNCEC ABSENT · TBMC PRESENT | |
| | | | | 2 = BQC NOT_CONSIDERED · PSCMEC DISABLE · SYNCEC PRESENT · TBMC NOT_PRESENT | A = BQC CONSIDERED · PSCMEC DISABLE · SYNCEC PRESENT · TBMC NOT_PRESENT | |
| | | | | 3 = BQC NOT_CONSIDERED · PSCMEC DISABLE · SYNCEC PRESENT · TBMC PRESENT | B = BQC CONSIDERED · PSCMEC DISABLE · SYNCEC PRESENT · TBMC PRESENT | |
| | | | | 4 = BQC NOT_CONSIDERED · PSCMEC ENABLE · SYNCEC ABSENT · TBMC NOT_PRESENT | C = BQC CONSIDERED · PSCMEC ENABLE · SYNCEC ABSENT · TBMC NOT_PRESENT | |
| | | | | 5 = BQC NOT_CONSIDERED · PSCMEC ENABLE · SYNCEC ABSENT · TBMC PRESENT | D = BQC CONSIDERED · PSCMEC ENABLE · SYNCEC ABSENT · TBMC PRESENT | |
| | | | | 6 = BQC NOT_CONSIDERED · PSCMEC ENABLE · SYNCEC PRESENT · TBMC NOT_PRESENT | E = BQC CONSIDERED · PSCMEC ENABLE · SYNCEC PRESENT · TBMC NOT_PRESENT | |
| | | | | 7 = BQC NOT_CONSIDERED · PSCMEC ENABLE · SYNCEC PRESENT · TBMC PRESENT | F = BQC CONSIDERED · PSCMEC ENABLE · SYNCEC PRESENT · TBMC PRESENT | |
| | | | | Trailer Brake (TB) • Transmission State (TS) | | |
| 720-05-02 | xx*x | xx-- | | 0 = TB disabled • TS State 1 | 4 = TB enabled • TS State 1 | |
| IPC | | | | 1 = TB disabled • TS State 2 | 5 = TB enabled • TS State 2 | |
| | | | | 2 = TB disabled • TS State 3 | 6 = TB enabled • TS State 3 | |
| | | | | 3 = TB disabled • TS State 4 | 7 = TB enabled • TS State 4 | |
| | | | | Trailer Brake Controller (TBC) • Turbo Boost (TB) • Digital Gauge Interface (DGI) • Nav Speed Sign (NSS) | | |
| 720-07-01 | xxxx | x*xx | xx-- | 0 = TBC disabled • TB No • DGI disabled • NSS NA | 8 = TBC enabled • TB No • DGI disabled • NSS NA | |
| IPC | | | | 1 = TBC disabled • TB No • DGI disabled • NSS ROW | 9 = TBC enabled • TB No • DGI disabled • NSS ROW | |
| | | | | 2 = TBC disabled • TB No • DGI enabled • NSS NA | A = TBC enabled • TB No • DGI enabled • NSS NA | |
| | | | | 3 = TBC disabled • TB No • DGI enabled • NSS ROW | B = TBC enabled • TB No • DGI enabled • NSS ROW | |
| | | | | 4 = TBC disabled • TB Yes • DGI disabled • NSS NA | C = TBC enabled • TB Yes • DGI disabled • NSS NA | |
| | | | | 5 = TBC disabled • TB Yes • DGI disabled • NSS ROW | D = TBC enabled • TB Yes • DGI disabled • NSS ROW | |
| | | | | 6 = TBC disabled • TB Yes • DGI enabled • NSS NA | E = TBC enabled • TB Yes • DGI enabled • NSS NA | |
| | | | | 7 = TBC disabled • TB Yes • DGI enabled • NSS ROW | F = TBC enabled • TB Yes • DGI enabled • NSS ROW | |
| | | | | Drive Control Menu (DCM) • Trailer Brake Controller (TBC) • Tunable Exhausts (TE) • Engine Rev Match (ERM) | | |
| 7D0-09-03 | xxxx | xxx* | xx-- | 0 = DCM Disabled · TBC Disabled · TE Disabled · ERM Disabled | 8 = DCM Enabled · TBC Disabled · TE Disabled · ERM Disabled | |
| APIM | | | | 1 = DCM Disabled · TBC Disabled · TE Disabled · ERM Enabled | 9 = DCM Enabled · TBC Disabled · TE Disabled · ERM Enabled | |
| | | | | 2 = DCM Disabled · TBC Disabled · TE Enabled · ERM Disabled | A = DCM Enabled · TBC Disabled · TE Enabled · ERM Disabled | |
| | | | | 3 = DCM Disabled · TBC Disabled · TE Enabled · ERM Enabled | B = DCM Enabled · TBC Disabled · TE Enabled · ERM Enabled | |
| | | | | 4 = DCM Disabled · TBC Enabled · TE Disabled · ERM Disabled | C = DCM Enabled · TBC Enabled · TE Disabled · ERM Disabled | |
| | | | | 5 = DCM Disabled · TBC Enabled · TE Disabled · ERM Enabled | D = DCM Enabled · TBC Enabled · TE Disabled · ERM Enabled | |
| | | | | 6 = DCM Disabled · TBC Enabled · TE Enabled · ERM Disabled | E = DCM Enabled · TBC Enabled · TE Enabled · ERM Disabled | |
| | | | | 7 = DCM Disabled · TBC Enabled · TE Enabled · ERM Enabled | F = DCM Enabled · TBC Enabled · TE Enabled · ERM Enabled | |
| | | | | VehicleInfo_TrailerLightModule (VITLM) • VehicleInfo_TrailerBrakeModule (VITBM) • Unused_3 (U) | | Cant currently change |
| 706-18-01 | xxxx | xxx* | xx-- | 0 = VITLM Not Present • VITBM Not Present • U Unused | 8 = VITLM Present • VITBM Not Present • U Unused | |
| IPMA | | | | 4 = VITLM Not Present • VITBM Present • U Unused | C = VITLM Present • VITBM Present • U Unused | |